


Model No. JR105D CORDLESS RECIPRO SAW



Model No.JR105D CORDLESS RECIPRO SAW

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/Old	Note1	Note2
001	165740-8	SHOE		1			
012	346526-1	CLAMPER		1			
013	251961-9	H.S.SET SCREW(FLAT POINT)M6X10		1			
014	310497-8	BLADE CLAMP		1	*		
014-1	310978-2	BLADE CLAMP	<	1			
015	256157-7	PIN 3		1			
016	266429-2	TAPPING SCREW 3X16		10			
017	183C31-3	HOUSING SET		1			
C10	263002-9	RUBBER PIN 4		3			
017		INC. 45					
019	851J07-7	JR105D NAME PLATE		1	*		
019-1	851J06-9	JR105D NAME PLATE	<	1			
020	266747-8	PAN HEAD SCREW M4X14 WITH WM		3			
021	319060-4	GEAR HOUSING		1			
022	213961-7	O RING 22		1			
023	346525-3	PLATE		1			
024	443185-3	FELT SEAL		1			
025	313220-0	SLIDER GUIDE		1			
026-1	313250-1	SLIDER N	S	1			
026	313269-0	SLIDER N		1			
027	313270-5	COLLARED SLEEVE 4		1			
028	142284-5	GEAR COMPLETE		1	*		
028-1	1410R5-8	GEAR COMPLETE	S	1			
029	211242-3	BALL BEARING 6902ZZ		1	*		
029-1	210294-1	BALL BEARING 6902ZZ	O	1			
030	266747-8	PAN HEAD SCREW M4X14 WITH WM		2			
031	256158-5	PIN 3		1			
032	629165-5	DC MOTOR		1	*		
032-1	629C94-0	DC MOTOR	S	1			
033	424467-2	CAP		1			
034	632F46-0	SWITCH UNIT		1			
C10	620447-8	LED CIRCUIT		1			
035	644813-5	TERMINAL		1			
036	632F66-4	LINE FILTER UNIT		1			
037	453072-8	SWITCH LEVER R		1			
038	233438-6	COMPRESSION SPRING 4		1			
039	454661-2	LOCK OFF LEVER R		1			
040	313219-5	LINK		1			
041	256158-5	PIN 3		1			
042	141128-6	SWITCH LEVER F COMPLETE		1			
043	319061-2	GEAR HOUSING COVER		1			
045	183C31-3	HOUSING SET		1			
C10	263002-9	RUBBER PIN 4		3			
045		INC. 17					
046	234258-1	COMPRESSION SPRING 7	S	1			

046	234258-1	COMPRESSION SPRING 7		1			
047	253874-0	FLAT WASHER 4		1			
048	922112-8	HEX. SOCKET HEAD BOLT M4X10		1			
049	285738-0	BEARING RETAINER 36		1			
050	265035-0	COUNTERSUNK HEAD SCREW M4 X10		2			
051	424597-9	RUBBER RING 23		1			
A01	783201-2	HEX. WRENCH 3		1			
A02	B-20432	RECIPROSAW BLADE 100MM		1			
A03	B-20404	RECIPROSAW BLADE 100MM		1			
A04	456128-6	BATTERY COVER		1			
A05	***DC10SA	DC10SA BATTERY CHARGER		1	*		
A05		COMPO-PARTS			*		
A05-1	***DC10SB	DC10SB BATTERY CHARGER	<	1			
A05-1		COMPO-PARTS					
A06B	197394-3	BATTERY BL1020B SET		2	*		
A06C	197402-0	BATTERY BL1040B SET		2	*		
A06-1 B	197396-9	BATTERY BL1021B SET	<	2	*		
A06-1 C	197406-2	BATTERY BL1041B SET	<	2	*		
A06-2 B	197396-9	BATTERY BL1021B SET	O	2			
A06-2 C	197406-2	BATTERY BL1041B SET	O	2			
A07	821662-9	PLASTIC CARRYING CASE		1			
C10	162315-4	LATCH		2			
F01	197390-1	BATTERY BL1015 SET		1			
F02	197391-9	BATTERY BL1015 SET		1			
F03	197393-5	BATTERY BL1016 SET		1			
F08	198968-3	BATTERY BL1016 SET		1	*		
F09	198969-1	BATTERY BL1016 SET (2PIECES)		1	*		
F10-1	198970-6	BATTERY BL1021B SET (2PIECES)	O	1	*		
F11-1	199002-2	BATTERY BL1041B SET (2PIECES)	O	1	*		

Please state Parts No. when your order.

Print Date 01/27/2025